

**Q.** Why I can't adjust volume when I open the FM radio Application?  
**A.** Please follow the steps below to solve the problem.

1. Locate the **Play TV MPEG2 → SW Configuration** as show below.



2. Choose **CD Player** as the **AUDIO** then press **OK**.

